




WA9000 Operating Instructions

Before operating this unit, please ensure that you have understood the control functions.



Control Panel

Points to remember:

- During operation you may hear the compressor stop, (the fan will continue to work) this is because the temperature has been reached on the temperature control dial. When the temperature rises the compressor will resume operation
- During humid wet days and high indoor temperatures the surround of the air outlet may form some condensation. This is a normal occurrence and can be removed with a tissue
- The interior of the air conditioner may give a sound of running water, this is the circulation of the coolant and is a normal occurrence
- The casing may let out a slight cracking type noise. This is due to contraction from the temperature variations and is a normal occurrence with this type of casing
- Do not operate the air conditioner below a room temperature of 18°C. The air conditioner will tend to frost up if temperatures are too low

The unit is fitted with a protective device. When it is turned off and then turned on immediately the fan will come into operation and the compressor will come in to operation after a few minutes

- **Timer control** – If you turn the dial onto CONT this will override the timing control and the unit will run continuously until turned to the off position. The numbers 1-8 indicate hour timing. By turning the dial to one of these numbers the unit will turn off automatically when the dial returns to the off position.
- **Fan speed control** – This operates FAN ONLY or COOLING and fan speed operation
- **Cooling control** – This dial operates the desired cooling temperature and will turn the compressor off automatically once the desired temperature is reached. The fan will continue running. When the room temperature rises the compressor will come on and resume the cooling operation. If you turn the dial fully clockwise to CONT this is the maximum cooling position
- **Bucket full alarm** – If the alarm indicator illuminates and the unit stops working please empty the water tank by removing the plug from the rubber hose on the bottom rear panel. Replace the plug and hose to normal position and turn the unit on. If the alarm indicator stays illuminated please call London Cool on 0800 440 444. The WA9000 has a unique system to dispel condensation automatically but on the odd occasion you may have to do this manually. Please call London Cool on 0800 440 444, if this occurs on a regular basis

Take Note: The unit is fitted with an overload protect-system which means when it is switched off and turned on immediately the compressor will not operate for a few minutes but will resume operation after this time.

Maintenance

Filter cleaning

- When using the unit in normal conditions, it is advisable to clean the filter every two weeks
- If you are using the unit in an area with excessive dust/fluff, it is advisable to clean the filter every week
- If the screen is not kept clean it can increase your power consumption and reduce the cooling efficiency
- Use a vacuum or a brush to remove fluff/dust from the filter
- Use lukewarm water and a very mild detergent when washing the filter and rinse with clean cold water

Front panel and housing

- Do not use chemicals or solvents for cleaning the unit
- Use a damp cloth for cleaning, and a mild detergent to remove any stubborn stains

Trouble Shooting

PROBLEM	CAUSES	RESOLUTIONS
Air conditioner stops operating	Power failure	Wait for the power to come back on
	The plug has not been plugged in	Insert the plug
	The timer setting dial has not been set	Set the timer setting dial to the correct position
	The fan speed control dial has not been set	Set the fan speed control dial to the correct position
	The tank full light is on – the water tank is full	Drain the condensation from the water tank
	Extension cord in use	Do not use an extension lead
Air conditioner stops in the middle of the operation	The indoor temperature has reached its designated temperature setting	Reset the temperature
	The designated operating time is complete	Reset the timer
	The tank full lamp is on – the water tank is full	Drain the condensation from the water tank
Air conditioner switches on and off constantly	Malfunction	Turn off the unit, an remove the plug, then contact London Cool on 0800 440 444
Air conditioner functions but the room is not cooled	Window or door is left open in the room	Close all windows and doors
	Heat source in the room is excessive	Additional units are required
	Saturated filter	Clean the filter
	Temperature setting is too high	Lower the temperature setting
The condensation overflows when the unit is moved	The internal water tank is full	Remove the water draining plug located at the units rear and drain the condensation from the tank

London Cool air conditioner rental and sales

This document has been compiled in good faith, but no representation is made or warranty given (either express or implied) as

to the completeness or accuracy of this information